

# ***Harvest Right 7 CFM Pump FR Drain Extension Install Tip***

You can install the FR Drain without removing the oil:

1. Unplug the pump, then tip the pump up on the motor end.
2. Loosen the lower brass factory drain cap and let it dangle.
3. Next hand tighten the FR Drain Extension, then gently tighten with a wrench, with about 2-3 lbs of pressure.  
(shut FR Drain, lever should be 90 degrees "L" to the right).
4. Finally, simply lean the pump back flat.

No Teflon tape needed.

Congratulations !

