

Frozen Right - Modular Mould Instructions

Wash all walls before initial use.

Temporary Guide

1. Using a Short Wall as a Temporary Guide, lay it sideways and insert the 1st Long Wall.

2. Using a 2nd Short Wall, insert into the slots across all the Long Walls. This is the Locking Wall.

Locking Wall

3. You can now remove the Temporary Guide.

4. Add a Short Wall on the opposite end. This will act as a Stabilizer.

Stabilizer

**5. Congratulations !
You can now make Custom Moulds.**

After batch is finished, remove the Short Walls 1st, holding them on the outer edges, while pushing down and against the Long Walls; using a wiggle lifting motion.