


# 3 Channel - Cable Cooler - Flow Chart



1. Plug freeze dryers into Wall Circuits #1, #3 & #4.
2. Plug both Cable Coolers into all freeze dryer's Pump Ports (outlets).
3. Plug "Leybold" pump into the 2nd Cable Cooler.
4. Plug both Cable Coolers into Wall Circuit #2.

Contact: Bryan at "The Epicenter" [www.theepicenter.com](http://www.theepicenter.com) for Leybold "Neo D 16" pump pricing.